


Unit SSR

Example

Control relay status ON/OFF



```
from m5stack import *
from m5ui import *
from uiflow import *
import unit

setScreenColor(0x222222)
ssr_0 = unit.get(unit.SSR, unit.PORTA)

while True:
    ssr_0.ssr_control(1)
    wait_ms(2)
```

API



```
ssr_0.ssr_control(1)
```

- Turn on or off the relay
 - ON
 - OFF