

Unit Earth

| 案例程序

打印 Earth Unit 检测的模拟和数字量



```
from m5stack import *
from m5stack_ui import *
from uiflow import *
import unit

screen = M5Screen()
screen.clean_screen()
screen.set_screen_bg_color(0xFFFFFF)
earth_0 = unit.get(unit.EARTH, unit.PORTB)

while True:
    print((str('Analog Value:') + str((earth_0.analogValue))))
    print((str('Digital Value:') + str((earth_0.digitalValue))))
    wait_ms(2)
```

| 功能说明

Get earth_0 Analog Value

earth_0.analogValue

- 获取指定设备 earth 的模拟值

Get earth_0 Digital Value

earth_0.digitalValue

- 获取指定设备 earth 的数字值

